




# SOPLADOR ASPIRADOR DBL40VA28 REF: DBL40CA28



VERSION 1.0



## SOPLADOR ASPIRADOR DBL40VA28 REF: DBL40CA28

PAG	POS	REFERENCIA	DESCRIPCION	PAG	POS	REFERENCIA	DESCRIPCION
P1	1	DBL40VA28/1	TORNILLO DBL-VA28	P1	32	DBL40VA28/32	CHAVETA DBL-VA28
P1	2	DBL40VA28/2	ARANDELA DBL-VA28	P1	33	DBL40VA28/33	RODAMIENTO DBL-VA28
P1	3	DBL40VA28/3	ARANDELA DBL-VA28	P1	34	DBL40VA28/34	CLIP BULON DBL-VA28
P1	4	DBL40VA28/4	TAPA ARRANCADOR DBL-VA28	P1	35	DBL40VA28/35	BULON DBL-VA28
P1	5	DBL40VA28/5	CARCASA TAPA MOTOR DBL-VA28	P1	36	DBL40VA28/36	PISTON DBL-VA28
P1	6	DBL40VA28/6	TOPE POMO DBL-VA28	P1	37	DBL40VA28/37	SEGMENTOS DBL-VA28
P1	7	DBL40VA28/7	CUERDA ARRACADOR DBL-VA28	P1	38	DBL40VA28/38	JUNTA CILINDRO DBL-VA28
P1	8	DBL40VA28/8	POMO ARRANCADOR DBL-VA28	P1	39	DBL40VA28/39	RODAMIENTO DBL-VA28
P1	9	DBL40VA28/9	MUELLE ARRANCADOR DBL-VA28	P1	40	DBL40VA28/40	CASQUILLO DBL-VA28
P1	10	DBL40VA28/10	CARCASA MUELLE DBL-VA28	P1	41	DBL40VA28/41	CARTER LADO TURBINA DBL-VA28
P1	11	DBL40VA28/11	POLEA CUERDA ARRANCADOR DBL-VA28	P1	42	DBL40VA28/42	RETEN DBL-VA28
P1	12	DBL40VA28/12	MUELLE TORSION DBL-VA28	P1	43	DBL40VA28/43	TORNILLO DBL-VA28
P1	13	DBL40VA28/13	POLEA ARRACADOR DBL-VA28	P1	44	DBL40VA28/44	ARANDELA DBL-VA28
P1	14	DBL40VA28/14	TRINQUETE DBL-VA28	P1	45	DBL40VA28/45	ARANDELA DBL-VA28
P1	15	DBL40VA28/15	ARANDELA DBL-VA28	P1	46	DBL40VA28/46	BOBINA DE ENCENDIDO DBL-VA28
P1	16	DBL40VA28/16	GRUPILA DBL-VA28	P1	47	DBL40VA28/47	PIPA BUJIA DBL-VA28
P1	17	DBL40VA28/17	TAPA CARCASA DBL-VA28	P1	48	DBL40VA28/48	ARANDELA DBL-VA28
P1	18	DBL40VA28/18	TORNILLO DBL-VA28	P1	49	DBL40VA28/49	TORNILLO DBL-VA28
P1	19	DBL40VA28/19	TAPA SILENCIOSO DBL-VA28	P1	50	DBL40VA28/50	ARANDELA DBL-VA28
P1	20	DBL40VA28/20	TORNILLO DBL-VA28	P1	51	DBL40VA28/51	ARANDELA DBL-VA28
P1	21	DBL40VA28/21	GOMA AJUSTE DBL-VA28	P1	52	DBL40VA28/52	TAPA SILENCIOSO DBL-VA28
P1	22	DBL40VA28/22	TUERCA DBL-VA28	P1	53	DBL40VA28/53	SILENCIOSO DBL-VA28
P1	23	DBL40VA28/23	VOLANTE MAGNETICO DBL-VA28	P1	58	DBL40VA28/58	ARANDELA DBL-VA28
P1	24	DBL40VA28/24	RETEN DBL-VA28	P1	59	DBL40VA28/59	CILINDRO DBL-VA28
P1	25	DBL40VA28/25	TORNILLO DBL-VA28	P1	60	DBL40VA28/60	JUNTA ADMISION DBL-VA28
P1	27	DBL40VA28/27	ARANDELA DBL-VA28	P1	61	DBL40VA28/61	SEPARADOR TERMICO DBL-VA28
P1	28	DBL40VA28/28	CARTER LADO VOLANTE DBL-VA28	P1	62	DBL40VA28/62	ARANDELA DBL-VA28
P1	29	DBL40VA28/29	JUNTA CARTER DBL-VA28	P1	63	DBL40VA28/63	ARANDELA DBL-VA28
P1	30	DBL40VA28/30	RODAMIENTO DBL-VA28	P1	64	DBL40VA28/64	TORNILLO DBL-VA28
P1	31	DBL40VA28/31	CIGÜEÑAL DBL-VA28	P1	65	DBL40VA28/65	JUNTA CARBURADOR DBL-VA28

VERSION 1.0



## SOPLADOR ASPIRADOR DBL40VA28 REF: DBL40CA28

PAG	POS	REFERENCIA	DESCRIPCION	PAG	POS	REFERENCIA	DESCRIPCION
P1	65	DBL40VA28/65	JUNTA CARBURADOR DBL-VA28	P1	95	DBL40VA28/95	TUBO GASOLINA DBL-VA28
P1	66	DBL40VA28/66	CARBURADOR DBL-VA28	P1	96	DBL40VA28/96	CLIP TUBO DBL-VA28
P1	67	DBL40VA28/67	PALOMILLA STARTER DBL-VA28	P1	97	DBL40VA28/97	FILTRO GASOLINA DBL-VA28
P1	68	DBL40VA28/68	TAPA DBL-VA28	P1	98	DBL40VA28/98	CORDON TAPON DEPOSITO DBL-VA28
P1	69	DBL40VA28/69	CARCASA FILTRO AIRE INTERIOR DBL-VA28	P1	99	DBL40VA28/99	JUNTA TAPON DBL-VA28
P1	70	DBL40VA28/70	ARANDELA DBL-VA28	P1	100	DBL40VA28/100	TAPON DEPOSITO DBL-VA28
P1	71	DBL40VA28/71	ARANDELA DBL-VA28	P1	101	DBL40VA28/101	SOPORTE MUELLE DBL-VA28
P1	72	DBL40VA28/72	TORNILLO DBL-VA28 DBL-VA28	P1	102	DBL40VA28/102	MUELLE ANTIVIBRATORIO DBL-VA28
P1	73	DBL40VA28/73	ELEMENTO FILTRO AIRE DBL-VA28	P1	103	DBL40VA28/103	CABLE PARE DBL-VA28
P1	74	DBL40VA28/74	TAPA FILTRO AIRE DBL-VA28	P1	104	DBL40VA28/104	INTERRUPTOR DBL-VA28
P1	75	DBL40VA28/75	TORNILLO FILTRO AIRE DBL-VA28	P1	105	DBL40VA28/105	TAPA INTERRUPTOR DBL-VA28
P1	76	DBL40VA28/76	TORNILLO DBL-VA28	P1	106	DBL40VA28/106	TORNILLO DBL-VA28
P1	77	DBL40VA28/77	TORNILLO DBL-VA28	P1	107	DBL40VA28/107	TAPA IZQUIERDA DBL-VA28
P1	78	DBL40VA28/78	EMPUÑADURA ASA INFERIOR DBL-VA28	P1	108	DBL40VA28/108	TORNILLO DBL-VA28
P1	79	DBL40VA28/79	ASA INFERIOR DBL-VA28	P1	109	DBL40VA28/109	ARANDELA DBL-VA28
P1	80	DBL40VA28/80	TAPA ASA INFERIOR DBL-VA28	P1	110	DBL40VA28/110	ARANDELA DBL-VA28
P1	81	DBL40VA28/81	SOPORTE ASA INFERIOR DBL-VA28	P1	111	DBL40VA28/111	EMPUÑADURA ASA DERECHA DBL-VA28
P1	82	DBL40VA28/82	TOPE ACELERADOR DBL-VA28	P1	112	DBL40VA28/112	MUELLE DBL-VA28
P1	83	DBL40VA28/83	EMPUÑADURA ASA IZQUIERDA DBL-VA28	P1	113	DBL40VA28/113	GATILLO DBL-VA28
P1	84	DBL40VA28/84	TAPA ASA SUPERIOR IZQUIERDA DBL-VA28	P1	114	DBL40VA28/114	JUNTA DBL-VA28
P1	85	DBL40VA28/85	TAPA ASA SUPERIOR DERECHA DBL-VA28	P1	115	DBL40VA28/115	ARANDELA DBL-VA28
P1	86	DBL40VA28/86	LEVA DBL-VA28	P1	116	DBL40VA28/116	TURBINA DBL-VA28
P1	87	DBL40VA28/87	CAÑA DBL-VA28	P1	117	DBL40VA28/117	CUCHILLA DBL-VA28
P1	88	DBL40VA28/88	TORNILLO DBL-VA28	P1	118	DBL40VA28/118	TUERCA IZQUIERDA DBL-VA28
P1	89	DBL40VA28/89	GATILLO ACELERADOR DBL-VA28	P1	119	DBL40VA28/119	INTERRUPTOR SEGURIDAD DBL-VA28
P1	90	DBL40VA28/90	VARILLA ACELERADOR DBL-VA28	P1	120	DBL40VA28/120	TAPA DERECHA VENTILADOR DBL-VA28
P1	91	DBL40VA28/91	TUBO RESPIRADERO DBL-VA28	P1	121	DBL40VA28/121	SOPORTE INTERRUPTOR DBL-VA28
P1	92	DBL40VA28/92	RESPIRADERO DBL-VA28	P1	122	DBL40VA28/122	TORNILLO DBL-VA28
P1	93	DBL40VA28/93	TUBO RETORNO DBL-VA28	P1	123	DBL40VA28/123	TAPA PROTECTOR DBL-VA28
P1	94	DBL40VA28/94	PASAMURO DBL-VA28	P1	124	DBL40VA28/124	TORNILLO DBL-VA28

VERSION 1.0



## SOPLADOR ASPIRADOR DBL40VA28 REF: DBL40CA28

PAG	POS	REFERENCIA	DESCRIPCION
P1	125	DBL40VA28/125	SEGURO TAPA ASPIRACION DBL-VA28
P1	126	DBL40VA28/126	RESORTE TAPA ASPIRACION DBL-VA28
P1	127	DBL40VA28/127	TAPA ASPIRACION DBL-VA28
P1	128	DBL40VA28/128	REJILLA DBL-VA28
P1	129	DBL40VA28/129	TUBO ASPIRADOR A DBL-VA28
P1	130	DBL40VA28/130	TUBO ASPIRADOR B DBL-VA28
P1	131	DBL40VA28/131	TUBO CURBADO SOPLADO DBL-VA28
P1	132	DBL40VA28/132	REJILLA SEGURIDAD DBL-VA28
P1	133	DBL40VA28/133	TUBO SOPLADO A DBL-VA28
P1	134	DBL40VA28/134	TUBO SOPLADO B DBL-VA28
P1	135	DBL40VA28/135	CODO SACO ASPIRADOR DBL-VA28
P1	136	DBL40VA28/136	SACO ASPIRADOR DBL-VA28